



## ***Some details before getting started***

Each Candelabro may need to be customised in terms of hanging lengths depending on the ceiling height and the space where it will be hung.

Please consider the following things that are important to specify when ordering the fixture.

Lzf will pass you a comprehensive form for the collection of data and will contact you to organise a conference call to review this information once collected.

1. Type of ceiling the lamp is going to be fixed to.

2. Blueprint of the room the lamp is going to be installed in. Indicate the main view (front). Indicate where windows are located.

3. This lamp composition requires a minimum ceiling height of 3,30 m and allows for a maximum ceiling height of 4,00 m.

Indicate the height of the ceiling the lamp is going to be fixed to. If the height of the ceiling is over 4 m please consult LZF.

4. Send 360° foto and video.

5. Installation requires 2 to 3 people. In case LZF is asked to send an installation technician the client would have to provide for 2 assistants. Estimated installation time is between 2 and 2 ½ days. (plus 1 day of preparation at the factory).

6. Indicate which kind of pulley (motorized, chains, etc.) is going to be used for lifting the canopy. The pulley as well as the fixture to the ceiling must be capable of bearing a minimum weight of 500 Kg.

7. Indicate if shipping is by ship or by plane.

8. If you do not have a dimming system please consult LZF. For the dimming system you need 1 fluorescent circuit and 2 normal circuits. In case you do not have them please consult LZF.



## ***Before you start***

1. Packaging is organized in such a way as to make installation easier: the numbers on the boxes indicate the order of installation. **IMPORTANT NOTICE: DO FOLLOW THE INSTALLATION INSTRUCTIONS.**
2. Once taken out of the wooden crate we recommend arranging the boxes according to the number indicated on them. Each lamp has an assigned number and all the components necessary for their installation are marked with the same number on labels with different colors.
3. Assemble the canopy underneath the spot where it is going to be fixed to.
4. Main power must be prepared for connecting the three circuits of the canopy.  
The installation kit contains two adaptors that allow for checking the correct functioning of all the lamps before lifting the canopy up to its final location.

5. Material necessary for the installation:

4 or 6 sawhorses. During the first phase of installation the canopy will be resting on the sawhorses.  
Pulley system capable of supporting a minimum weight of 500 Kg / Canopy.  
Ceiling fixture system capable of supporting a minimum weight of 500 Kg.  
Certified chain with a link capacity of 500 Kg.  
One short and one long ladder (necessary when the canopy is hanging at 1,20 m.)  
Certified carabiners.

The canopy comes with a lacquered or upholstered finishing; when it is resting on the sawhorses the foam protectors included in the package should be used.

6. Tools necessary for the installation:

INCLUDED IN THE PACKAGE:

- Hexagonal spanner for Totem no. 3
- Flat screwdriver for cable glands
- 3 extra cables for Minimikado (3 m.) and Totem (2 m.)
- 1 level

NOT INCLUDED IN THE PACKAGE:

- Adjustable or fixed wrench nos. 13 and 10
- Star bit screwdriver (manual or automatic)

7. Please let us know what kind of sockets you use.